

Pre-Op:

Vancomycin 1 gram & Gentamycin 5mg Implants –

Penile Prosthesis:

Confirm with Rep

SURGEON SPECIAL REQUEST:**Removal of Prosthesis:**

Two-Set Ups (small table or extra mayo stand) – ***if removal is infected***

Gentamycin 80 mg

Betadine Solution

Hydrogen Peroxide

Culture tubes

ZERO INFECTION IPP PROTOCOL

- All preoperative antibiotics have to be completed before surgical incision (Give before taking the pt to OR suite in order to allow proper tissue level)
- ***Inside the OR:*** Replace BLANKETS and SHEETS with sterile half sheet prior to entering the OR suite to minimize contamination.
- Ask patient to void in pre-op (straight catheterize patient if did not void- irrigate distal urethra with betadine prior to prep)
- ***Skin Prep*** – Hibiclens and them Cloraprep – perform a thorough skin prep making 100% sure the foreskin is pulled back and scrubbed diligently. ***If this is difficult to do, please notify surgeon prior to proceeding.***
- Dry off Hibiclens before applying the Chloraprep!
- All OR scrubbed personnel are to DOUBLE GLOVE with frequent glove changes.
- Limit OR traffic once room is open
- Implant boxes are NOT to be open (Assembly & Reservoir) until patient is fully draped.